

X-AIR WIDE ENTRY OPTION

- Mount the tubes 142 on the parts 111142.
- Position the wide entry parts 111142B on the parts 111142.
- Shorten the tubes 139 of 215 mm from the bottom
- Position the tubes 138, 139 and 140.
- Install the keel as shown in section A2-1 and A2-2 of the assembly manual
- Mark and drill the holes in the back plates of the part 111142B and bolt it with the part 111142 and tube 140.
- drill the lower front tube of part 111142B trough part 111142 and bolt them.
- Drill the low part of tube 139 through part 111142B and bolt.
- Continue the assembly as shown in the following of the manual.

